

ENSURE THAT AS YOU FOLLOW THESE INSTRUCTIONS, YOU FIRMLY SECURE ALL PARTS WITH NUTS AND BOLTS.

STEP | 1

Push down on the centre of the cart to fold out the unit.



STEP | 2

Unfold the padding and place it at the bottom the cart.



STEP | 3

Take the spanner provided and remove the safety bolts from each corner of the cart.



STEP | 4

Twist a Shade Pole into each screw at the corners of the cart.



STEP | 5

A. Position Long and short Shade Supports at the top of each Shade Pole.

B. Gently place the Shade Cover on top, and attach securely with the provided bolts with the allen key.



STEP | 6

Adjust the handle, as desired.



CONGRATULATIONS!

You have assembled your Vuly Rover wagon cart.