


INSTALLATION

PARTS LIST

- 1x Goal Mat
- 1x Soccer Ball
- 1x Pump


STEP | 1

Slide the Mid Tube from your Vuly Mini through the loops at the top of the Soccer Goal.




STEP | 2

Slide Leg Tubes from your Vuly Mini through the loops on both sides of the Soccer Goal.




STEP | 3

Insert Shoulder Tubes from your Vuly Mini into the tops of both Leg Tubes.



STEP | 4

Attach the Mid Tube and Shoulder Joiners to your Vuly Mini, as per your Vuly Mini Manual.



CONGRATULATIONS!

You have attached the Soccer Goal to your Vuly Mini.

DISCLAIMER

ATTENTION!

Safety information, installation and use instructions. Read prior to installing and using the swings.

See [VulyPlay.com/support](https://www.vulyplay.com/support) for any updates to these instructions.

WARNING!

- Minimum user age - 6 years. Only for domestic and outdoor use.
- Maximum user weight per swing station - 50 kg (110lb)
- Maximum combined user weight per swing set section - 120kg (265lb)
- Adult assembly required. Adult supervision required at all times.
- Ensure that the Swing Set is secured with anchors or bolts before use.



ADULT SUPERVISION IS REQUIRED AT ALL TIMES WHILST EQUIPMENT IS IN USE.
VULY CARES ABOUT SAFETY.